

16 MM LENS 10K Mode	1/125th	1/60th	1/40th	1/30th	1/20th	1/15th	1/10th	1/8th
Highest Resolution	7 MIN	8 MIN	8 MIN	9.7 MIN	13.5 MIN	15.7 MIN	23.5 MIN	32 MIN
Med								
Low								
Lowest Resolution								

16 MM LENS 10K Mode	1/125th	1/60th	1/40th	1/30th	1/20th	1/15th	1/10th	1/8th
Highest Resolution	12.4 MIN	15.5 MIN	15.2 MIN	19 MIN	25.5 MIN	31.5 MIN	45MIN	60 MIN
Med	3.2 MIN	6 MIN	6 MIN	7.5 MIN	11 MIN	13 MIN	19.2 MIN	29 MIN
Low	1.4 MIN	2.5 MIN	2.5 MIN	3.4 MIN	5.1 MIN	6.6 MIN	10 MIN	13.5 MIN
Lowest Resolution	55 SEC	60 SEC	1.25 MIN	1.5 MIN	2.5 MIN	3.1 MIN	4.6 MIN	6.5 MIN

28 MM LENS 20K Mode	1/125th	1/60th	1/40th	1/30th	1/20th	1/15th	1/10th	1/8th
Highest Resolution	13 MIN	16 MIN	14.5 MIN	19.5 MIN	26 MIN	31 MIN	45MIN	60 MIN
Med	3.5 MIN	6 MIN	6 MIN	7.5 MIN	11 MIN	13 MIN	19.2 MIN	26.4 MIN
Low	1.5 MIN	2.5 MIN	2.5 MIN	3.4 MIN	5.1 MIN	6.6 MIN	10 MIN	13 MIN
Lowest Resolution	55 SEC	60 SEC	1.2 MIN	1.5 MIN	2.5 MIN	3.1 MIN	4.6 MIN	6.5 MIN

50 MM LENS 40K mode	1/125th	1/60th	1/40th	1/30th	1/20th	1/15th	1/10th	1/8th
Highest Resolution	26 MIN	30 MIN	30.5 MIN	39 MIN	50 MIN	61 MIN	95 MIN	121 MIN
Med	6.7 MIN	10 MIN	12 MIN	14.6 MIN	20.2 MIN	26 MIN	39.5 MIN	51 MIN
Low	2.3 MIN	4.5 MIN	5.2 MIN	6.6 MIN	10.2 MIN	13 MIN	19.5 MIN	26.5 MIN
Lowest Resolution	1.6 MIN	2.1 MIN	2.5 MIN	3 MIN	4.7 MIN	6.2 MIN	9.5 MIN	12.5 MIN

All tests performed with Apple iBook 500 with Firewire interface.

All times are for 390 degree scan with 30 degree overlap. Times are approximate. Actual scan times may vary depending on host computer.

Yellow indicates that Highest shadow detail must be used at these settings.

Red area indicates a setting that is NOT recommended.